



For unlisted items, call us at **954-340-0500**
Last updated 06/1/2010

	Assembly Description	Assembly Number	Spare Part Number	Description
Soft Goods	Stage IV 3000	50-SM34	50A52-S	Shell Assy/Mat S2/S3 PolyVinyl
Soft Goods	Stage IV 3000	50-SM34	50A52-S-HG	ShellAsy/HosGd
Soft Goods	Stage IV 3000	50-SM34	50A34LAL	Coverlet/LAL/Zipper/ S2/ S3
Soft Goods	Stage IV 3000	50-SM34	50A52-AC	Air cell/Large S2/S3/
Soft Goods	Stage IV 3000	50-SM34	DP-P10410	CPR Pull/PlsticMold/Red/Urethn
Soft Goods	Stage IV 3000	50-SM34	52A822	CPR/ThinBlock/HoseAsy/1 zone M
Soft Goods	Stage IV 3000	50-SM34	50A52-ML	Mattress Loop Assy/ S2/S3
Controller	Stage IV 3000	23-SM3000	MF-F60G	Air Intake Filter
Controller	Stage IV 3000	23-SM3000	MF-GFR	Guard/ Filter Retainer/ 60mm
Controller	Stage IV 3000	23-SM3000	CQ-FP1	QckDis/ Femal/ GreyThd/APC100-04
Controller	Stage IV 3000	23-SM3000	CQ-MP1	QckDis/M/1/4-18NPT/APC240-04
Controller	Stage IV 3000	23-SM3000	CQ-MB5	QckDis/m/1/4-18tdLAL/LC240-04
Controller	Stage IV 3000	23-SM3000	HN-P-1	PEMS
Controller	Stage IV 3000	23-SM3000	DP-P10210	Lid/Plastic/Black/S2,S3
Controller	Stage IV 3000	23-SM3000	EH-CO1	ElecCord/Rt.Angle/Detatch/13FT
Controller	Stage IV 3000	23-SM3000	EK-CT18	Crimp Term/18-22AWG/.250/ROHS/
Controller	Stage IV 3000	23-SM3000	ES-S1	Switch/RockerOnOff/dpsLgt/All
Controller	Stage IV 3000	23-SM3000	EK-SF	Socket/PwrCord/AllContr
Controller	Stage IV 3000	23-SM3000	MF-60	Fan/ Muffin/ 60mm ROHS